



Step-By-Step on Installing Firmware for SARES 16

1. Put the upgrade folder on a USB stick, it must be called "upgrade"

*****NOTE: The Upgrade Folder must contain the files for the SARES 16*****

2. Plug-in USB into USB port on front of SARES unit
3. Press Setup button on the SARES unit and enter password
4. Scroll down to Password and press Select button
5. Highlight Admin Password and press Select button
6. Type in 12341234 all on the first line and press Select button
7. System will go into test mode
8. Select USB Upgrade and press Select button
9. Press the Esc or Select button when prompt
10. Scroll down to Boot Application and press Select button
11. Remove USB stick